

3D LAMINATE VS. THERMOFOIL

Layers Make All the Difference

3D Laminate

Backer
THICKER FOIL
 Abrasion resistant layer
 Surf(x) layer*
 Top coat

Standard Thermofoil

Backer
 Foil
 Top coat



*protects against cleaners

Durability

Test	HPL	HP 3D Laminate
Hoffman Scratch	400g	1000g
NEMA Wear	400 cycles	1,400 cycles
NEMA Boiling Water	None	None/Moderate
NEMA Ball Impact	50"	>118"



Cleanability

- Seamless, non-porous
- Easily cleaned with soap and water
- Can be safely cleaned and disinfected with the following:

- | | | |
|----------------------------------|-----------------------------|------------------------|
| • Asepticare TB-11 | • Clorox germicidal wipes | • PDI Sanicloth HB |
| • Bleach 5:1 | • Dispatch Spray | • PDI Sanicloth Plus |
| • Bleach-Rite disinfecting spray | • Fade-A-Dyne stain remover | • SaniZide Plus |
| • Cavicide surface disinfectant | • Lysol spray disinfectant | • Virex II 256 cleaner |
| • Citrace germicide | • Precise hospital cleaner | • Virox AHP5 wipes |

Where should I use 3D Laminate?



Healthcare



Work surfaces



Dining

Surfacetech